Machines made in Austria for
Road Construction – Agriculture - Forestry

Personal Introduction

Jakob Holzer

Founder & CEO

Dieter Grossenberger

Head of Sales & Technical Support

The Company

Headquarter:

PTH Products Maschinenbau GMBH

Lechen 14

8692 Neuberg

Austria

www.pthproducts.com

PTH Products – GLOBAL



Our Products

- PTH Ripper
- PTH Crusher
- PTH Speed Grader / PTH Speedy
- PTH Compactor
- PTH Multi Crusher Series
- PTH ECO Crusher Series
- PTH aBr Additional Breaking System
- PTH WSF & Micro Crusher

PTH Machines Overview

What can you do with PTH Machines?

Customers use our machines for:

- Road construction (rural road, concrete, asphalt)
- Farmland claiming and re-cultivation
- General stone& building rubble crushing purposes
- Stabilization of areas (e.g. with cement powder)
- Forest mulching

How to repair a rural road with PTH

Step 1

Loosen the old road or field material with the PTH Ripper

- Old asphalt roads
- Rural roads
- Mountain roads
- Hauling roads
- Field / Farmland

How to repair a rural road with PTH

Step 2

Crush the loosen material with one of the PTH Crushers

- PTH Micro Crusher
- PTH ECO Crusher
- PTH Crusher Special
- PTH Crusher HD Series
- PTH Multi Crusher

How to repair a rural road with PTH

Step 3

Shape the crushed material with one of the PTH Graders

- PTH ECO Grader
- PTH Speedy
- PTH Speed Grader G2

How to claim Farmland with PTH

Step 1

Mulch away all trees, bushes, branches, etc… on top

- PTH ECO Crusher Series
- PTH Crusher Special Series
- PTH Crusher HD Series

How to claim Farmland with PTH

Step 2

On demand loosen the ground – then crush the material

- PTH Ripper
- PTH ECO Crusher Series
- PTH Crusher Special Series
- PTH Crusher HD Series

How to claim Farmland with PTH

Step 3

Use a commercial seeding machine or rotary cultivator – seeding machine combination to plant new grassland, corn, etc…

How to claim Farmland with PTH - Result

PTH Crusher Versions

PTH Micro Crushers	–	from 30 to 60 HP
PTH ECO Crushers	–	from 80 to 160 HP
PTH Crushers Special	–	from 120 to 270 HP
PTH Crushers HD Series	–	from 270 to 400 HP
PTH Multi Crushers	–	from 300 to 600 HP

Important requirements

What does a commercial tractor need to drive a PTH Crusher?

- Creeper gear or automatic transmission
- 3 Point Linkage (depending on Crusher KAT 1 / 2 / 3 / 4
- PTO Shaft with 1000 rpm (540 or 750 is also OK)



- *Recommended: Forestry tires with steel inlays*

Machines Overview – PTH Micro Crusher

PTH Micro Crusher

- Micro Crusher MC 900
- Micro Crusher MC 1150
- Micro Crusher MC 1400

Operation depth: max. 150mm

Machines Overview – PTH ECO Crusher

PTH ECO Crusher

- ECO Crusher 150
- ECO Crusher 200

Operation depth: max. 200 mm

Machines Overview – PTH ECO Crusher

PTH ECO Crusher
Land clearing

Machines Overview – PTH ECO Crusher

PTH ECO Crusher
Agriculture

Machines Overview – PTH Crusher Special

PTH Crusher Special

- Crusher Special 200 (RS)
- Crusher Special 250 (RS)

Operation depth: 250 / 350 mm

Machines Overview – PTH Crusher HD

PTH Crusher HD

- Crusher 2000 HD (RS)
- Crusher 2500 HD (RS)

Operation depth: 250 / 350 mm

Machines Overview – PTH Multi Crusher

PTH Multi Crusher

- Multi Crusher 1800
- Multi Crusher 2000
- Multi Crusher 2200
- Multi Crusher 2400

Operation depth: 350 / 500 mm

PTH Products Contact

PTH Products Maschinenbau GmbH

Lechen 14

A-8692 Neuberg an der Mürz

Österreich

Tel.Büro: (+43) 03857 / 80530

Fax: (+43) 03857 / 80530-4

Email: office (at) pthproducts.com

Web: www.pthproducts.at